



MODEL 1036-2 WALL MOUNTED SERVICE STATION

Specifications:

Height:	73 in.
Length:	32 in.
Width:	25 in.
Color:	Beige
Electrical:	110VAC
Plumbing:	Plumbing specs by request
Shipping Weight:	250 lbs. approx.

The Wall Mounted Service Unit is fabricated of fiberglass with all plumbing and electrical hook-ups designed for easy installation. The unit is completely equipped with all the best quality chrome and stainless steel fixtures and accessories to improve efficiency and reduce operating costs.

Design Features:

- Stainless Steel Sink
- Electric Waste Disposal Unit
- Hot and Cold Water Tempering unit with Lever Handle
- Centralever self closing pre-rinse valve with 10 ft. flexible vinyl hose
- Utility Faucet with Elbow Handle and Swivel Spout
- Electrical outlet
- Hydro Aspirator equipped with a built-in vacuum breaker to prevent water backflow.
- Available with your choice of:
Stainless Steel Mirrored Cabinet with a towel dispenser, soap dispenser, utility shelf and recessed shelf or Open Stainless Steel Shelving designed for storage of chemical bottles.

