



MODEL 1036-R101 TWO BODY MOBILE REFRIGERATOR



Specifications:

Length:	97 inches
Width:	38.5 inches
Height:	75 inches overall
Door:	27 inches x 53 inches
Temp:	38 degrees F

Design Features:

- Unit ships fully assembled, simply plug it into an outlet and the unit is operational
Available in 110v or 220v, please specify at time of order
- Panel finishes:
 - Exterior front panel - 22 gauge Type 304 stainless steel with a No. 4 finish
 - Exterior balance- 20 gauge stucco embossed aluminum
 - Interior walls/ceiling - 20 gauge stucco embossed aluminum
 - Interior floor - 14 gauge smooth aluminum
- Insulation: 4 inch foamed in place polyurethane insulation
- Flush mount door with clear opening of 27 inches x 42 inches
- Heavy-duty chrome plated hardware for long lasting use
- Telescoping Rack Mechanism: Three piece telescoping carriage fabricated of aluminum extrusion with maintenance free nylon rollers
- Body Trays: Fabricated of 18 gauge type 304 stainless steel with a No. 4 finish. Trays are provided with built-in hand slots and are constructed for heavy-duty use with continuous welded corners
- Casters: Four 6 inch diameter casters, two casters are rigid; two are swivel type with wheel brakes
- Includes dial thermometer fixture and evapoway pan for condensate removal